


Art. 160.1305



**Art. 160.1305**

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
1-1	160.1305-R001P	Grundkörper für Hydraulikeinheit	Oil Cylinder Assembly	1
1-10	160.1305-R002P	Kupferdichtung	Copper Washer	2
1-11	160.1305-R003P	Bolzen	Bolt	2
1-12	160.1305-R004P	Feder	Spring	1
1-13	160.1305-R005P	Bolzen	Rod	1
1-14	160.1305-R006P	Ventilsitz	Ball Seat	1
1-15	160.1305-R007P	Kupferdichtung	Copper Washer	1
1-16	160.1305-R008P	Mutter	Nut	2
1-17	160.1305-R009P	Feder	Spring	1
1-18	160.1305-R010P	Ölablassventil	Oil release Valve	1
1-19	160.1305-R011P	O-Ring	O-ring	1
1-2	160.1305-R012P	Stahlkugel	Steel Ball	1
1-20	160.1305-R013P	Unterlegscheibe	Washer	1
1-21	160.1305-R014P	Sicherungsring	Snap Ring	1
1-22	160.1305-R015P	Abllassventil	Release Valve	1
1-23	160.1305-R016P	Abllassventilpedal	Release Valve Pedal	1
1-24	160.1305-R017P	Bolzen	Pin	2
1-25	160.1305-R018P	Bolzen	Pin	2
1-26	160.1305-R019P	Feder	Spring	1
1-27	160.1305-R020P	Y-Dichtung	Y-seal	1
1-28	160.1305-R021P	O-Ring	O-ring	1
1-29	160.1305-R022P	Pumpkolben	Pump Plunger	1
1-3	160.1305-R023P	Ventilsitz	Ball Seat	1
1-30	160.1305-R024P	Federabdeckung	Spring Cover	1
1-31	160.1305-R025P	Sicherungsring	Snap Ring	1
1-32	160.1305-R026P	Kugellager	Bushing	1
1-33	160.1305-R027P	Bolzen	Pin	1
1-34	160.1305-R028P	Fusspedal	Foot Pedal	1
1-35	160.1305-R029P	Sicherungsring	Snap Ring	2
1-36	160.1305-R030P	Bolzen	Pin	1
1-37	160.1305-R031P	Öleinfüllschraube	Reservoir Fill Screw	1

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
1-38	160.1305-R032P	Schraube	Vented Reservoir Screw	1
1-39	160.1305-R033P	Dichtungsring	Sealing Gasket	1
1-4	160.1305-R034P	Feder	Spring	1
1-40	160.1305-R035P	Mutter	Nut	1
1-41	160.1305-R036P	Bolzen	Bolt	1
1-42	160.1305-R037P	Handgriff	Handle Sleeve	2
1-43	160.1305-R038P	Zugstange	Draw Bar	1
1-44	160.1305-R039P	Nylonring	Nylon Gasket	1
1-45	160.1305-R040P	O-Ring	O-ring	1
1-46	160.1305-R041P	O-Ring	O-ring	1
1-47	160.1305-R042P	Kugellager	Bushing	1
1-48	160.1305-R043P	Sicherungsring	Snap Ring	1
1-49	160.1305-R044P	Kugellager	Bushing	1
1-5	160.1305-R045P	Schraube	Screw	1
1-50	160.1305-R046P	Innerer Zylinder	Inner Cylinder	1
1-51	160.1305-R047P	Kugellager	Bushing	1
1-52	160.1305-R048P	Kugellager	Bushing	1
1-53	160.1305-R049P	Staubdichtung	Dust Seal	1
1-54	160.1305-R050P	Schraubkappe	Screw Cap	1
1-55	160.1305-R051P	Staubdichtung	Dust Seal	1
1-56	160.1305-R052P	Kugellager	Bushing	1
1-57	160.1305-R053P	Hubkolben	Piston Rod	1
1-58	160.1305-R054P	O-Ring	O-ring	1
1-59	160.1305-R055P	Kugellager	Bushing	1
1-6	160.1305-R056P	Unterlegscheibe	Washer	1
1-60	160.1305-R057P	Schraubkappe	Screw Cap	1
1-61	160.1305-R058P	Staubdichtung	Dust Seal	1
1-62	160.1305-R059P	Staubdichtung	Dust Seal	1
1-63	160.1305-R060P	Entlüftungsschraube	Air Bleed Screw	1
1-64	160.1305-R061P	Sicherungsring	Retainer Ring	1
1-65	160.1305-R062P	Abstandsbolzen	Heel Block	1

**Art. 160.1305**

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
1-66	160.1305-R063P	Ventilschraube	Valve Plug	1
1-67	160.1305-R064P	Feder	Spring	1
1-68	160.1305-R065P	O-Ring	O-ring	2
1-69	160.1305-R066P	Nylonring	Nylon Collar	2
1-7	160.1305-R067P	Bolzen	Bolt	1
1-70	160.1305-R068P	Durchflussventilgehäuse	Flow Valve Body	1
1-71	160.1305-R069P	Stopschraube	Stopper Screw	1
1-72	160.1305-R070P	Stahlkugel	Steel Ball	1
1-73	160.1305-R071P	Magnet	Magnet	1
1-74	160.1305-R072P	Gummischeibe	Rubber Washer	1
1-75	160.1305-R073P	Sicherheitsventilniete	Safety Valve Rivet	1
1-8	160.1305-R074P	Stahlkugel	Steel Ball	3
1-9	160.1305-R075P	Feder	Spring	1
2-1	160.1305-R076P	Lenkrolle 1	Swivel Caster	2
2-2	160.1305-R077P	Lenkrolle 2	Swivel Caster	2
2-3	160.1305-R078P	Bolzen	Bolt	8
2-4	160.1305-R079P	Unterlegscheibe	Lock Washer	12
2-5	160.1305-R080P	Halter für Lenkrolle	Leg	2
2-6	160.1305-R081P	Mutter und Unterlegscheibe	Nut and Washer	4
2-7	160.1305-R082P	Hydraulikeinheit	Complete Hydraulic Assembly	1
3-1	160.1305-R083P	Halterung	Bracket	1
3-10	160.1305-R084P	Schraube	Screw	1
3-11	160.1305-R085P	Schraube	Screw	1
3-12	160.1305-R086P	Betätigungsstange 1	Handle B	1
3-13	160.1305-R087P	Betätigungsstange 2	Handle A	1
3-14	160.1305-R088P	Bolzen	Shaft	2
3-15	160.1305-R089P	Bolzen	Shaft	2
3-16	160.1305-R090P	Kugellager	Bushing	4
3-17	160.1305-R091P	Bolzen	Pin	4
3-18	160.1305-R092P	Bolzen	Pin	2

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
3-19	160.1305-R093P	Bolzen	Bolt	1
3-2	160.1305-R094P	Halterung	Bracket C	2
3-20	160.1305-R095P	Bolzen	Bolt	1
3-21	160.1305-R096P	Sicherungsmutter	Lock Nut	2
3-22	160.1305-R097P	Spanngurt	Strap	1
3-23	160.1305-R098P	Bolzen	Bolt	1
3-24	160.1305-R099P	Unterlegscheibe	Lock Washer	1
3-25	160.1305-R100P	Unterlegscheibe	Washer	1
3-26	160.1305-R101P	Bolzen	Bolt	1
3-27	160.1305-R102P	Sicherungsmutter	Lock Nut	1
3-28	160.1305-R103P	Handgriff	Grip	1
3-29	160.1305-R104P	Unterlegscheibe	Washer	2
3-3	160.1305-R105P	Halterung	Bracket B	1
3-30	160.1305-R106P	Bolzen	Bolt	2
3-31	160.1305-R107P	Aufnahmeplatte komplett	Complete Saddle Assembly	1
3-32	160.1305-R108P	Sicherungsring	Retainer Ring	4
3-4	160.1305-R109P	Halterung	Bracket A	1
3-5	160.1305-R110P	Arretierung Komplett	Retainer Plate Assembly	4
3-5A	160.1305-R111P	Arretierung	Retainer Plate	4
3-5B	160.1305-R112P	Feder	Spring Assembly	4
3-5C	160.1305-R113P	Niete	Rivet	4
3-6	160.1305-R114P	Bolzen	Pin	4
3-7	160.1305-R115P	Arretierung	Retainer Plate	1
3-8	160.1305-R116P	Einstellhaltung	Adjusting Bracket	1
3-9	160.1305-R117P	Einstellhaltung	Adjusting Bracket A	1